



QUICK START
INSTRUCTIONS

ReNuLite

Headlight Restoration Kit



BEFORE
Cloudy and Yellowed



AFTER
Clear and Like NEW

SAFETY EQUIPMENT REQUIRED:
Safety glasses, gloves and an organic vapor respirator



Step 1

Thoroughly clean headlight with glass cleaner or water. Carefully mask off the headlight and surrounding area.



Step 2

Wet or dry sand the headlight lens with 600 grit sandpaper. For quicker results, use a dual-action sander. During and following sanding, use water and a towel to clean the headlight and surrounding areas of all sanding residue.



Step 3

Using Presta Headlight Restoration Crème, #136816, buff the headlight using a 3" wool buffing pad with a drill attachment provided in the kit. Buff the headlight until you achieve a clear finish.



Step 4

Wipe headlight thoroughly with Presta Lens Drier, #138608, and a clean lint-free towel to make sure it is dry. The surface of the headlight needs to be dry and dust-free for proper sealant application.



Step 5

Apply ReNuLite Headlight Sealant, #137306, following the directions on the can. Allow 8 minutes for product to run, flatten and flash. Pull vehicle into sunlight or use UVA light to cure. See #137306 Tech Data for more information.